INSTALLATION INSTRUCTIONS



Nut Style Panel Mount

1. **CoreMax** Cores should remain in protective packaging until assembly is required to ensure cleanliness and eliminate damage. Just prior to assembly remove the **CoreMax** Core from packaging tray.

2. Insert seat thru hole in panel and thread nut onto seat.



3. Braze SEAT ONLY onto tube or valve block before installing/threading Core into seat.



CoreMax





