## REPLACEMENT INSTRUCTIONS



## KSMxxxx Main Seal Replacement RQD Valved In-Line Connector

## **DESCRIPTION:**

Main Seal Replacement for internally valved, RQD Connector.



Please thoroughly read the instructions to properly replace the seal. The connector is designed to provide a safe, reliable leak-tight seal and connection when properly maintained and operated.

- The main seal is specifically designed for the application. DO NOT use any substitute seal.
- Follow the replacement instructions carefully.
- DO NOT use excessive force to replace seal as this may damage the seal or connector.
- Use caution when disassembling the connector.

## **REPLACEMENT:**

- 1) Have connector in its activated position. Piston should be forward for easiest access to the main seal.
- 2) Using a repair pick, or similar tool, remove the main seal as shown in the diagram. Exercise caution so as not to scratch or deform the seal groove. This could cause a potential leak path.

3) Using the same tool, work the replacement seal into the seal groove. Exercise caution so as not to puncture or tear the seal during replacement. This could cause a potential leak path.



FasTest, Inc. warrants its products against defects of workmanship and/or material for 12 months from the date of the sale by FasTest, Inc. This warranty is void if the product is misused, tampered with or used in a manner that is not in accordance with FasTest, Inc. recommendations and/or instructions. FasTest, Inc. is not liable for consequential or other damages including, but not limited to, loss, damage, personal injury, or any other expense directly or indirectly arising from the use of or inability to use its products either separately or in combination with other products. ALL OTHER WARRANTIES EXPRESSED OR IMPLIED, WHETHER ORAL OR WRITTEN, INCLUDING BUT NOT LIMITED TO WARRANTIES OR MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE EXPRESSLY EXCLUDED.

Remedy under this warranty is limited to replacement of the product or an account credit in the amount of the original selling price, at the option on FasTest, Inc. All allegedly defective products must be returned prepaid transportation to FasTest, Inc. along with information describing the products performance, unless disposition in the field is authorized in writing by FasTest, Inc.



www.fastestinc.com

Roseville, MN Ph: 1-800-444-2373 Fax: 651-645-7390

WP108 Rev A 10/7/2010